



## KEYLESS SECURITY LOCK USER INSTRUCTION

### TO LOCK:

1. Knob & white arrow must be in 12 O'clock and "Unlock" position
2. Spin dials to set a 1-4 number combination.
3. Turn knob to 9 O'clock and "Lock" position.
4. Spin dials to scramble combination.



**Lock**

### TO UNLOCK:

1. Spin dials to present combination.
2. Turn knob to "unlock" position.
3. Leave knob in "unlock" position and scramble your combination for next user.



**Unlock**