




KEYLESS1 USER INSTRUCTIONS

TO LOCK

1. Close the door.
2. Make sure knob is pointing up to , then set any 4 digit code.
3. Turn knob to .
4. Scramble the code.

TO UNLOCK

1. Re-enter your code.
2. Turn the knob up to .
3. Open the door.
4. Scramble the code for the next user.



See how it works:



KEYLESS.CO